







































































| Original  | Replacement | Original  | Replacement           |
|---|-------------|---|-----------------------|
|      | Power       |      | Power                 |
|      | Mute        |      | Mute / Dimmer         |
|      | 1           |      | 1                     |
|      | 2           |      | 2                     |
|      | 3           |      | 3                     |
|      | 4           |      | 4                     |
|      | 5           |      | 5                     |
|      | 6           |      | 6                     |
|      | 7           |      | 7                     |
|      | 8           |      | 8                     |
|     | 9           |     | 9                     |
|    | DTV / ATV   |    | D.Menu / Top          |
|    | 0           |    | 0                     |
|    | Recall      |    | Back / Return         |
|    | P.Mode      |    | Picture / Format      |
|    | S.Mode      |    | Sound / Title         |
|    | Sleep       |    | Sleep / Timer         |
|    | Vol +       |    | Vol+                  |
|    | MTS         |    | Audio / Lang I/II     |
|    | CH +        |    | CH+ / Page+           |
|    | Vol -       |    | Vol-                  |
|    | REC List    |    | Smart / List          |
|    | CH -        |    | CH- / Page-           |
|    | FAV List    |    | Fav / Marker / PC     |
|    | REC         |    | Rec / Rec Mode        |
|    | Freeze      |    | Pause / Step / Freeze |
|    | Menu        |    | Menu / Home           |
|   | Up          |   | Up                    |
|  | Source      |  | AV / Input / RDS      |
|  | Left        |  | Left                  |
|  | Enter       |  | OK                    |
|  | Right       |  | Right                 |
|  | Exit        |  | Exit / Cancel / Clear |
|  | Down        |  | Down                  |





| Original   | Replacement   | Original   | Replacement  |
|--|---|--|--|
|  Display                |  Display / Media             |  Hold |  Shift + Stop / |
|  Red                    |  Red / Netflix / Search      |  Text |  Text / Goto    |
|  Green                  |  Green / APP / Repeat        |  |  |
|  Yellow                 |  Yellow / YouTube / Repeat   |  |  |
|  Blue                   |  Blue / Prime Video / Random |  |  |
|  << / Guide             |  << / Tune-                  |  |  |
|  << / Guide             |  Guide / EPG / -/--          |  |  |
|  Play/Pause / Timeshift |  Play / Slow                 |  |  |
|  >> / Aspect            |  >> / Tune+                  |  |  |
|  I<< / Cancel           |  I<< / Preset-               |  |  |
|  >>I / Subpage         |  >>I / Preset+              |  |  |
|  Stop / Index         |  Info / Angle              |  |  |
|  Stop / Index         |  Stop / Hold               |  |  |
|  TV / Radio           |  TV/Radio /                |  |  |
|  Subtitle             |  Subtitle / EQ             |  |  |
|  Reveal               |  Setup / OPT /             |  |  |
|  Size                 |  Zoom / Size               |  |  |

