



	Original	Replacement		Original	Replacement
	Power		Power		EPG
	Mute		Mute		Guide
	Format		Format		Menu
	SAT		Smart		Info
	TV/STB		Media		Up
	TV/Radio		TV/R		Down
	1		1		Right
	2		2		Left
	3		3		Ok
	4		4		Vol +
	5		5		Vol -
	6		6		Exit
	7		7		Ch +
	8		8		Ch -
	9		9		Red/Text
	0		0		Green/Audio
	Back		Back		Yellow/Sub.T
					Blue/Find





	Original	Replacement	Original	Replacement
	Edit	 3D		
	OPT	 Options		
	USB/PVR	 AV		
	FAV	 Pre Ch		
	<<	 <<		
	Play	 Play		
	Pause	 Pause		
	>>	 >>		
	Stop	 Stop		
	Pg Dn	 I<<		
	Pg Up	 >>I		
	Rec	 Rec		

