





















































Original	Replacement	Original	Replacement
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	PIP/Audio		3D
	[<>]		Format
	?		Smart
	Mute		Mute
	Z/Disc Menu		Menu
	i/OSD		Info
	TXT		Text
	TV-G		Guide
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	P+		Ch +
	P-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Red/Image/I>		Red
	Green/Timer		Green
	Yellow/@		Yellow
	Blue/Sound		Blue
	Play		Play
	Pause		Pause























	Original	Replacement	Original	Replacement
	Stop			
	<<			
	>>			
	I<			
	>I			













Original	Replacement	Original	Replacement
 Power	 Power	 Z/Disc Menu	 Menu
 1	 1	 Up	 Up
 2	 2	 Down	 Down
 3	 3	 Right	 Right
 4	 4	 Left	 Left
 5	 5	 OK	 Ok
 6	 6	 P+	 Ch +
 7	 7	 P-	 Ch -
 8	 8	 Vol+	 Vol +
 9	 9	 Vol-	 Vol -
 0	 0	 Red/Image/I>	 Red
 PIP/Audio	 3D	 Green/Timer	 Green
 [ <> ]	 Format	 Yellow/@	 Yellow
 ?	 Smart	 Blue/Sound	 Blue
 i/OSD	 Info	 Play	 Play
 TXT	 Text	 Pause	 Pause
 TV-G	 Guide	 Stop	 Stop


























































	Original	Replacement	Original	Replacement
	<<	 <<		
	>>	 >>		
	>	 >>		
	<	 <<		








Original	Replacement	Original	Replacement
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	PIP/Audio		3D
	[<>]		Format
	?		Smart
	Mute		Mute
	i/OSD		Info
	TXT		Text
	Z/Disc Menu		Menu
	TV-G		Guide
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	P+		Ch +
	P-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Red/Image/ >		Red
	Green/Timer		Green
	Yellow/@		Yellow
	Blue/Sound		Blue
	Play		Play
	Pause		Pause









































































	Original	Replacement	Original	Replacement
	Stop			
	<<			
	>>			
	<			
	>			













Original	Replacement
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 PIP/Audio	 3D
 [<>]	 Format
 ?	 Smart
 i/OSD	 Info
 TXT	 Text
 TV-G	 Guide

Original	Replacement
 Z/Disc Menu	 Menu
 P+	 Ch +
 P-	 Ch -
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 Red/Image/I>	 Red
 Green/Timer	 Green
 Yellow/@	 Yellow
 Blue/Sound	 Blue
 Play	 Play
 Pause	 Pause
 Stop	 Stop





	Original	Replacement		Original	Replacement
	<<		<<		
	>>		>>		
	<		<<		
	>		>>		

