



Original	Replacement
	Standby
	Power
	Yellow / YouTube / Repeat
	Green / APP / Repeat
	Eject / Surround
	Subtitle / EQ
	Info / Angle
	Audio / Lang I/II
	Display / Media
	CH+ / Page+
	CH- / Page-
	Exit / Cancel / Clear
	TV/Radio /
	Setup / OPT /
	Up
	Enter
	Left
	Play / Slow

Original	Replacement
	Right
	Right
	D.Menu / Top
	Down
	Sound / Title
	I<< / Preset-
	<< / Tune-
	>> / Tune+
	>>I / Preset+
	Shift + Slow
	Shift + Play /
	Shift + Pause / Step /
	Pause / Step / Freeze
	Stop / Hold
	1
	2
	3
	Zoom / Size
	4



