









































































Original		Replacement		Original		Replacement	
	Power		Power		9		9
	Energy		Display / Media		TTX		Text / Goto
	Picture		Picture / Format		0		0
	Sound		Sound / Title		Recall		Back / Return
	Mute		Mute / Dimmer		Menu		Menu / Home
	Audio		Audio / Lang I/II		Up		Up
	Subtitle		Subtitle / EQ		Input		AV / Input / RDS
	16:9/4:3		Shift + Zoom /		Left		Left
	Sleep		Sleep / Timer		OK		OK
	1		1		Right		Right
	2		2		Exit		Exit / Cancel / Clear
	3		3		Down		Down
	4		4		Info		Info / Angle
	5		5		Vol+		Vol+
	6		6		Home		Shift + Menu /
	7		7		EPG/Hold		Guide / EPG / -/-
	8		8		CH+		CH+ / Page+





Original	Replacement
 Vol-	 Vol-
 FAV List	 Fav / Marker / PC
 Size	 Zoom / Size
 Play	 Smart / List
 CH- / Page-	
 Play / Slow	
 Stop / Hold	
 << / Tune-	
 >> / Tune+	
 Tv Pause	 Pause / Step / Freeze
 Goto	 Shift + Text /
 I<< / Preset-	
 >>I / Preset+	
 Rec / Rec Mode	
 Red / Netflix / Search	
 Green / APP / Repeat	
 Yellow / YouTube / Repeat	

Original	Replacement
 Blue	 Blue / Prime Video / Random

