







































| Original | Replacement |
|--|---|
|  VHS/DVD Power |  Power |
|  Direct TV Rec |  Subt |
|  VHS/DVD |  Smart |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  Cancel / Reset |  Exit |
|  Input Select |  Guide |
|  CH+ / Tracking/V-Lock+ |  Ch + |
|  CH- / Tracking/V-Lock- |  Ch - |

| Original | Replacement |
|---|---|
|  Create Chapter |  TV/R |
|  I<< Skip |  I<< |
|  Skip >>I |  >>I |
|  REW / << Slow/Search |  << |
|  FF / Slow/Search |  >> |
|  Stop |  Stop |
|  Pause |  Pause |
|  Play |  Play |
|  Direct Navigator / Top Menu |  D. Menu |
|  Functions |  List |
|  Up |  Up |
|  Left |  Left |
|  Enter |  Ok |
|  Right |  Right |
|  Down |  Down |
|  Sub Menu |  Menu |
|  Return |  Back |





| Original | | Replacement | | Original | | Replacement | |
|---|------------------------|---|-------|---|------------|---|------------|
|  | VHS/DVD Power |  | Power |  | ShowView |  | Media |
|  | Direct TV Rec |  | Subt |  | I<< Index |  | I<< |
|  | VHS/DVD |  | Smart |  | Index >>I |  | >>I |
|  | 1 |  | 1 |  | REW |  | << |
|  | 2 |  | 2 |  | FF |  | >> |
|  | 3 |  | 3 |  | Stop |  | Stop |
|  | 4 |  | 4 |  | Pause |  | Pause |
|  | 5 |  | 5 |  | Play |  | Play |
|  | 6 |  | 6 |  | Up |  | Up |
|  | 7 |  | 7 |  | Left |  | Left |
|  | 8 |  | 8 |  | Enter |  | Ok |
|  | 9 |  | 9 |  | Right |  | Right |
|  | 0 |  | 0 |  | Down |  | Down |
|  | Cancel / Reset |  | Exit |  | Return |  | Back |
|  | Input Select |  | AV |  | Prog/Check |  | Sleep |
|  | CH+ / Tracking/V-Lock+ |  | Ch + |  | Display |  | Info |
|  | CH- / Tracking/V-Lock- |  | Ch - |  | Jet Rew |  | Shift + << |



