







































































Original	Replacement	Original	Replacement
 Power	 Power	 Return	 Back / Return
 i	 Info / Angle	 Vol +	 Vol+
 1	 1	 Vol -	 Vol-
 2	 2	 Up	 Up
 3	 3	 Down	 Down
 4	 4	 Right	 Right
 5	 5	 Left	 Left
 6	 6	 CH List	 Smart / List
 7	 7	 Enter / CH List	 OK
 8	 8	 P +	 CH+ / Page+
 9	 9	 P -	 CH- / Page-
 0	 0	 Audio I/II	 Audio / Lang I/II
 Input Select	 AV / Input / RDS	 Text	 Text / Goto
 Picture Size	 Picture / Format	 P <--> P	 Fav / Marker / PC
 Guide (EPG)	 Guide / EPG / -/--	 [≡?]	 TV/Radio /
 Mute	 Mute / Dimmer	 Subtitle	 Subtitle / EQ
 Menu	 Menu / Home	 Freeze	 Pause / Step / Freeze





Original	Replacement	Original	Replacement
	Size		Zoom / Size
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random

