



























Original	Replacement
 Power	 Power
 Source	 AV
 Mute	 Mute
 Auto	 Smart
 Display	 Info
 Sleep	 Sleep
 TV	 Media
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Original	Replacement
	 Guide
	 Pre Ch
	 Red
	 Green
	 Yellow
	 Blue
	 Up
	 Left
	 Menu
	 Ok
	 Right
	 Down
	 Ch +
	 Ch -
	 Vol +
	 Vol -

