




























































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Menu		Menu / Home
	0		0
	Sortie		Exit / Cancel / Clear
	Vol+		Vol+
	Up		Up
	P+		CH+ / Page+
	Left		Left
	OK		OK
	Right		Right
	Vol-		Vol-
	Down		Down
	P-		CH- / Page-
	Info		Info / Angle
	FAV		Fav / Marker / PC
	Audio		Audio / Lang I/II
	EPG		Guide / EPG / -/-
	Red/RCL		Red / Netflix / Search
	Green		Green / APP / Repeat
	Pause		Pause / Step / Freeze
	Yellow/Sous		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Text		Text / Goto
	SAT		Shift + 0





Original	Replacement
Tv/R	TV/Radio /
V.F	Setup / OPT /
AV	AV / Input / RDS

Original	Replacement

