

TOSHIBA
PC/PROJECTOR
TLP-X4500

Mandis Shop S.L.
Sant Cugat del Vallès - Barcelona
info@mandis.es

Layout Keys	Direct	Shift	Layout Keys	Direct	Shift
OFF	STANDBY / ON				
ON	STANDBY / ON				
SRC SEARCH	VOLUME				
AUTO MODE	AUTO				
HIDE BLANK	[/] / BLANK				
ASPECT RE-SYNC	ASPECT				
MENU INFO	MENU				
EXIT LAMP	ESC	RESET			
PICT FREEZE	FREEZE				
MUTE FOCUS	MUTE				
ZOOM/KEYSTONE+	ZOOM+	MAGNIFY – ON			
ZOOM/KEYSTONE-	ZOOM-	MAGNIFY – OFF			
VOL/PAGE+	LENS SHIFT +	FOCUS+			
VOL/PAGE-	LENS SHIFT -	FOCUS-			
/\	UP				
√	DOWN				
<	LEFT / PREVIOUS				
>	RIGHT / NEXT				
OK	ENTER				
1 POINTER	POSITION				
2 MOUSE LEFT B.	MAGNIFY – ON				
3 MOUSE RIGHT B.	MAGNIFY – OFF				
4 VGA1					
5 VGA2					
6 COMP	RGB				
7 S-VIDEO					
8 VIDEO	VIDEO				
9 HDMI					
0 LAN					
USB	[/ \] / KEYSTONE				
PIP	P IN P				