






























































Original		Replacement		Original		Replacement	
	Power		Power		Vol-		VOL -
	TV/FM		TV/R		CH+		CH +
	Scan		VOD		CH-		CH -
	Zoom		WIDE		Mute		MUTE
	1		1		Source		SRC
	2		2		+		RIGHT
	3		3		-		LEFT
	4		4		Function		OK
	5		5		Freq Up		Fast Forward
	6		6		Freq Down		Rewind
	7		7		Freeze		Pause
	8		8		Reset		EXIT
	9		9		Seek ↑		UP
	0		0		Seek ↓		DOWN
	+100		-/-- / EPG				
	Loop		P/C / FAV				
	Vol+		VOL +				

