








































Original	Replacement
 Standby	 Power
 Mute	 Mute / Dimmer
 AV	 AV / Input / RDS
 Tv/Radio	 TV/Radio /
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Menu	 Menu / Home
 TXT	 Text / Goto
 Exit	 Exit / Cancel / Clear

Original	Replacement
 Back	 Back / Return
 OK	 OK
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 CH+	 CH+ / Page+
 CH-	 CH- / Page-
 Vol+	 Vol+
 Vol-	 Vol-
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Audio	 Audio / Lang I/II
 White/Info	 Info / Angle
 List	 Smart / List





Original	Replacement	Original	Replacement
	Guide / EPG / --		
	+  Shift + Green / APP /		
	Subtitle / EQ		

