



Original		Replacement		Original		Replacement	
	Power		Power		FAV		Fav / Marker / PC
	Mute		Mute / Dimmer		Audio		Audio / Lang I/II
	V.Format		Picture / Format		[≡]		Text / Goto
			Pause / Step / Freeze		[...]		Subtitle / EQ
	A/R		Display / Media		Timer		Sleep / Timer
	Tv/Radio		TV/Radio /		Menu		Menu / Home
	1		1		Up		Up
	2		2		P+		CH+ / Page+
	3		3		Guide		Guide / EPG / -/--
	4		4		Left		Left
	5		5		Vol-		Vol-
	6		6		OK/List		Smart / List
	7		7		OK/List		OK
	8		8		Right		Right
	9		9		Vol+		Vol+
	Recall		Back / Return		Exit		Exit / Cancel / Clear
	0		0		Down		Down





Original	Replacement	Original	Replacement
	P-		CH- / Page-
	i		Info / Angle
	Red/F1		Red / Netflix / Search
	Green/F2		Green / APP / Repeat
	Yellow/F3		Yellow / YouTube / Repeat
	Blue/F4		Blue / Prime Video / Random
	SAT		Shift + 0
	AUX		Shift + 7

