

































Original	Replacement
 Power	 Power
 Open/Close	 Eject
 Power Tv	 +  Shift + Power
 TV/DVD	 TV/R
 3D Surr	 Dual
 PIP	 3D
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 AV	 AV

Original	Replacement
 AV Tv	 +  Shift + AV
 PR+ Tv	 Ch +
 PR- Tv	 Ch -
 Vol+ Tv	 Vol +
 Vol- Tv	 Vol -
 Mute Tv	 Mute
 O)))/Audio	 +  Shift + Dual
 [...] /Subtitle	 Subt
 Camera/Angle	 Options
 Rec	 Rec
 Rec Mode	 +  Shift + Rec
 Timer Rec	 Blue
 << Scan	 <<
 Scan >>	 >>
 I<< Skip	 I<<
 Skip >>I	 >>I
 Pause/Step	 Pause





Original	Replacement	Original	Replacement
	Play		Play
	Stop		Stop
	Home		Smart
	Menu/List		Menu
	Return		Back
	Display		Info
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	Lock/Timeshift	+	Shift + 3D
	Marker		Guide
	Search	+	Shift + TV/R
	Setup		D. Menu
	Dubbing	+	Shift + Options
	I.Skip	+	Shift + Subt

Original	Replacement	Original	Replacement
	Title		Red
	CHP ADD		Sleep
	Thumbnail		Format
	Random		Media
	Repeat		Text
	A-B	+	Shift + Play
	Zoom	+	Shift + Eject
	Clear		Exit

