



















































Original		Replacement		Original		Replacement	
	Power		Power		Green		Green
	Play		Play		Yellow		Yellow
	Pause		Pause		Blue		Blue
	<<		<<		CH+		Ch +
	>>		>>		CH-		Ch -
	I<<		I<<		Vol+		Vol +
	>>I		>>I		Vol-		Vol -
	Stop		Stop		Source		AV
	Rec		Rec		Menu		Menu
	Tv/TXT		Text		DVB		Smart
	Cancel		Back		Exit		Exit
	Reveal		D. Menu		Up		Up
	Hold		Options		Down		Down
	Size		Eject		Right		Right
	Subpage		Shift + Subt		Left		Left
	Index		Info		OK		Ok
	Red		Red		1		1



