





































| Original | Replacement |
|--|--|
|  Power |  Power |
|  Mute |  Mute |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  ASPECT |  Format |
|  P.C. |  Pre Ch |
|  MENU |  Menu |
|  SOURCE |  Shift + AV |
|  Up |  Up |

| Original | Replacement |
|---|--|
|  Right |  Right |
|  Down |  Down |
|  Left |  Left |
|  OK |  Ok |
|  Exit |  Exit |
|  Display |  Info |
|  Vol + |  Vol + |
|  Vol - |  Vol - |
|  CH + |  Ch + |
|  CH - |  Ch - |
|  Sound |  Dual |
|  PIC |  Shift + Format |
|  NICAM |  Media |
|  SLEEP |  Sleep |
|  TV |  Smart |
|  AV |  AV |
|  HDMI |  Shift + Media |





| | Original | Replacement | |
|---|----------|--|--|
|  | SCART1 |  Subt | |
|  | Y.PB.PR |  +  Shift + Subt | |
|  | RECALL |  Back | |
|  | Red |  Red | |
|  | Green |  Green | |
|  | Yellow |  Yellow | |
|  | Blue |  Blue | |
|  | Reveal |  Play | |
|  | Hold |  Pause | |
|  | List |  List | |
|  | Index |  Stop | |
|  | Subpage |  Rec | |
|  | Size |  3D | |
|  | Auto |  Guide | |
|  | Text |  Text | |
| | | | |
| | | | |

| Original | Replacement |
|----------|-------------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

