







































































Original	Replacement	Original	Replacement
 Power	 Power	 Left	 Left
 1	 1	 P+	 Ch +
 2	 2	 P-	 Ch -
 3	 3	 Vol+	 Vol +
 4	 4	 Vol-	 Vol -
 5	 5	 Red	 Red
 6	 6	 Sound	 Dual
 7	 7	 Green	 Green
 8	 8	 Picture	 Format
 9	 9	 Yellow	 Yellow
 0	 0	 Feature	 Media
 M	 Menu	 Blue	 Blue
 --	 Guide	 Install	 Smart
 Up	 Up	 AV	 AV
 OK	 Ok	 TV	 TV/R
 Down	 Down	 TXT	 Text
 Right	 Right	 Mute	 Mute

