























































































Original	Replacement	Original	Replacement
 PIP/[]	 Picture / Format	 OK	 OK
 Web	 Smart / List	 Green	 Green / APP / Repeat
 Back/End	 Exit / Cancel / Clear	 Yellow	 Yellow / YouTube / Repeat
 DR+/Pop-Up-M	 D.Menu / Top	 <<	 << / Tune-
 */Zoom	 Zoom / Size	 Play	 Play / Slow
 Blue/Marker	 Blue / Prime Video / Random	 >>	 >> / Tune+
 Red	 Red / Netflix / Search	 Rec	 Rec / Rec Mode
 Text/Disc-M	 Text / Goto	 Pause	 Pause / Step / Freeze
 Info	 Info / Angle	 Stop	 Stop / Hold
 Vol+	 Vol+	 7	 7
 Vol-	 Vol-	 Mute	 Mute / Dimmer
 P+	 CH+ / Page+	 1	 1
 P-	 CH- / Page-	 2	 2
 Up	 Up	 3	 3
 Down	 Down	 4	 4
 Right	 Right	 5	 5
 Left	 Left	 6	 6









































































	Original	Replacement		Original	Replacement
	Power		Power		
	8		8		
	9		9		
	0		0		
	AV		AV / Input / RDS		
	EPG		Guide / EPG / -/--		
	Home		Shift + Menu /		
	Menu		Menu / Home		









































































Original	Replacement	Original	Replacement
	Mute		Mute / Dimmer
	Power		Power
	DR+/Pop-Up-M		D.Menu / Top
	*/Zoom		Zoom / Size
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	AV		AV / Input / RDS
	EPG		Guide / EPG / -/--
	Home		Menu / Home
	PIP/[]		Picture / Format
	Text		Text / Goto
	Back		Back / Return
	Info		Info / Angle
	Vol+		Vol+
	P+		CH+ / Page+
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Vol-		Vol-
	Down		Down
	P-		CH- / Page-
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue/Marker		Blue / Prime Video / Random





Original	Replacement
 DR+ / Pop-Up-M	 D.Menu / Top
 */Zoom	 Zoom / Size
 Blue/Marker	 Blue / Prime Video / Random
 Back/End	 Exit / Cancel / Clear
 PIP/[]	 Picture / Format
 Red	 Red / Netflix / Search
 Info	 Info / Angle
 Vol+	 Vol+
 Vol-	 Vol-
 P+	 CH+ / Page+
 P-	 CH- / Page-
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 OK
 Green	 Green / APP / Repeat

Original	Replacement
 Yellow	 Yellow / YouTube / Repeat
 <<	 << / Tune-
 Play	 Play / Slow
 >>	 >> / Tune+
 Rec	 Rec / Rec Mode
 Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold
 7	 7
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 Power	 Power
 8	 8



























































	Original	Replacement	Original	Replacement





















Original	Replacement
 Mute	 Mute / Dimmer
 Power	 Power
 DR+/Pop-Up-M	 D.Menu / Top
 */Zoom	 Zoom / Size
 Web	 Smart / List
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0 AV	 0
 AV	 AV / Input / RDS
 EPG	 Guide / EPG / -/--

Original	Replacement
 Home	 Shift + Menu /
 PIP/[]	 Picture / Format
 Text	 Text / Goto
 Menu	 Menu / Home
 Back/End	 Exit / Cancel / Clear
 Info	 Info / Angle
 Vol+	 Vol+
 P+	 CH+ / Page+
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Vol-	 Vol-
 Down	 Down
 P-	 CH- / Page-
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat





Original	Replacement	Original	Replacement
 Yellow	 Yellow / YouTube / Repeat		
 Blue/Marker	 Blue / Prime Video / Random		
 <<	 << / Tune-		
 Play	 Play / Slow		
 >>	 >> / Tune+		
 Rec	 Rec / Rec Mode		
 Pause	 Pause / Step / Freeze		
 Stop	 Stop / Hold		

Original	Replacement

