






















































	Original	Replacement		Original	Replacement
	Power		Power		Shift + Guide
	Mute		Mute		Recall
	Auto		Smart		Tv Menu
	P.Mode		Shift + Format		Exit
	S.Mode		Shift + Dual		Guide
	Display		Shift + Info		Source
	Audio / Nicam		Dual		Up
	1		1		Down
	2		2		Right
	3		3		Left
	4		4		Enter
	5		5		CH -
	6		6		Ch +
	7		7		Vol -
	8		8		Vol +
	9		9		Text
	0		0		<<





Original	Replacement	Original	Replacement
>>	>>	Repeat	Shift + Text
Hold	Options	FAV +	Shift + Up
Index	Info	Subtitle	Subt
I<<	I<<	Media	Media
Size	Format	Rec	Rec
>>I	>>I		
Play/Pause	Play		
Stop / Subpage	Stop		
Zoom / Reveal	Eject		
Sleep	Sleep		
Tv / Radio	TV/R		
Red	Red		
Green	Green		
Yellow	Yellow		
Blue	Blue		
FAV	Pre Ch		
FAV -	Shift + Down		

