



Original		Replacement		Original		Replacement	
	Power		Power		Vol +		Vol +
	Input		AV		Vol -		Vol -
	Q.Menu		D. Menu		Mute		Mute
	Info		Info		Fav		Pre Ch
	?		List		3D		3D
	1		1		P +		Ch +
	2		2		P -		Ch -
	3		3		Recent		Eject
	4		4		Home		Smart
	5		5		My Apps		Media
	6		6		Back		Back
	7		7		Live Menu		Menu
	8		8		Exit		Exit
	9		9		Up		Up
	0		0		Down		Down
	Guide		Guide		Right		Right
	Q.View		Format		Left		Left





Original	Replacement	Original	Replacement
	Ok		Ok
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Text		Text
	T.Opt		Options
	App/*		Shift + Media
	Stop		Stop
	Play		Play
	Pause		Pause
	<<		<<
	>>		>>
	Rec/*		Rec
	Subtitle		Subt
	AD		Shift + Subt
	Tv/Rad		TV/R

