









































































Original	Replacement	Original	Replacement
 Power	 Power	 Mute	 Mute
 Netflix	 Media	 P+	 Ch +
 Source	 AV	 P-	 Ch -
 1	 1	 Internet	 Smart
 2	 2	 Menu	 Menu
 3	 3	 Q Menu	 D. Menu
 4	 4	 Back	 Back
 5	 5	 Exit	 Exit
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Right	 Right
 9	 9	 Left	 Left
 0	 0	 OK	 Ok
 TV	 TV/R	 i	 Info
 Recall	 Pre Ch	 [>]	 Format
 Vol+	 Vol +	 EPG	 Guide
 Vol-	 Vol -	 YouTube	 Shift + Media





Original	Replacement	Original	Replacement
 FPlay	 Shift + Smart		
 TXT	 Text		
 Lang.	 Dual		
 Subt.	 Subt		
 [ + ]	 3D		
 <<	 <<		
 Pause	 Pause		
 >>	 >>		
 Rec	 Rec		
 Play	 Play		
 Stop	 Stop		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		

