







































































Original		Replacement		Original		Replacement	
	Power		Power		Home		Smart
	Source		AV		P+		Ch +
	1		1		P-		Ch -
	2		2		[i+]		Info
	3		3		Guide		Guide
	4		4		Back		Back
	5		5		Exit		Exit
	6		6		Up		Up
	7		7		Down		Down
	8		8		Right		Right
	9		9		Left		Left
	0		0		OK		Ok
	Lang.		Dual		Red		Red
	TXT		Text		Green		Green
	Vol+		Vol +		Yellow		Yellow
	Vol-		Vol -		Blue		Blue
	Mute		Mute		<<		<<





	Original	Replacement		Original	Replacement
	Pause				
	>>				
	Rec				
	Play				
	Stop				

