






















Original	Replacement
Power	Power
TV/RAD	TV/R
Bollywood	Format
[↔]/Ratio	3D
Away/Mosquito	Media
Source	AV
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
List	List

Original	Replacement
Info	Info
Vol+	Vol +
Vol-	Vol -
Mute	Mute
FAV	Pre Ch
Guide	Guide
P+	Ch +
P-	Ch -
Back	Back
Exit	Exit
Home	Smart
*	Menu
Q.Menu	D. Menu
Text	Text
T.OPT	Options
Up	Up
Down	Down





Original	Replacement	Original	Replacement
 Right	 Right		
 Left	 Left		
 OK	 Ok		
 AD/*	 Subt		
 Rec	 Rec		
 Stop/Live TV	 Stop		
 <<	 <<		
 Play	 Play		
 Pause	 Pause		
 >>	 >>		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		

