







Original		Replacement		Original		Replacement	
	Power		Power		0		0
	Mute		Mute		Menu		Menu
	FAV		Pre Ch		Exit		Exit
	Subtitle		Subt		EPG		Guide
	Info		Info		Swap		Media
	TTX		Text		Up		Up
	List		List		Down		Down
	Recall		Back		Right		Right
	1		1		Left		Left
	2		2		OK		Ok
	3		3		Vol+		Vol +
	4		4		Vol-		Vol -
	5		5		Pg Up		Shift + Up
	6		6		PG Dn		Shift + Down
	7		7		CH+		Ch +
	8		8		CH-		Ch -
	9		9		>>		>>



