



Original	Replacement	Original	Replacement
 Power	 Power	 Hold/EPG	 Guide
 Mute	 Mute	 Red	 Red
 1	 1	 Green	 Green
 2	 2	 Yellow	 Yellow
 3	 3	 Blue	 Blue
 4	 4	 Vol+	 Vol +
 5	 5	 Vol-	 Vol -
 6	 6	 I-II	 Dual
 7	 7	 Source	 AV
 8	 8	 Freeze	 Options
 9	 9	 CH+	 Ch +
 0	 0	 CH-	 Ch -
 Back/S.Page	 Back	 Sleep	 Sleep
 Text	 Text	 Menu	 Menu
 Index/PVR List	 Smart	 DTV/Radio	 TV/R
 Rec/Reveal	 Rec	 Exit	 Exit
 Zoom/T.Shift	 Eject	 Aspect	 3D





	Original	Replacement		Original	Replacement
	P.Mode	 Format		FAV	 Pre Ch
	S.Mode	 +  Shift + Dual		FAV+/Repeat	 +  Shift + Ch +
	Up	 Up		FAV-/A-B	 +  Shift + Ch -
	Down	 Down			
	Right	 Right			
	Left	 Left			
	OK	 Ok			
	Media	 Media			
	Info/Slow	 Info			
	Step/Subtitle	 Subt			
	Play	 Play			
	Pause	 Pause			
	I<<	 I<<			
	>>I	 >>I			
	Stop	 Stop			
	<<	 <<			
	>>	 >>			

