































| Original | | Replacement | | Original | | Replacement | |
|---|------------|---|--------|---|----------|---|---------|
|  | Power |  | Power |  | Recall |  | Back |
|  | Mute |  | Mute |  | Text |  | Text |
|  | Red |  | Red |  | Subtitle |  | Subt |
|  | Blue/Pause |  | Blue |  | USB |  | AV |
|  | Green |  | Green |  | Menu |  | Menu |
|  | Yellow |  | Yellow |  | Exit |  | Exit |
|  | Audio |  | Dual |  | EPG |  | Guide |
|  | Zoom |  | Eject |  | FAV |  | Pre Ch |
|  | Info |  | Info |  | Up |  | Up |
|  | << |  | << |  | Down |  | Down |
|  | >> |  | >> |  | Right |  | Right |
|  | I<< |  | I<< |  | Left |  | Left |
|  | >>I |  | >>I |  | OK |  | Ok |
|  | Play |  | Play |  | Find |  | Options |
|  | Stop |  | Stop |  | SAT |  | Format |
|  | Rec |  | Rec |  | HDMI |  | Smart |
|  | Pause |  | Pause |  | F1 |  | Media |





| Original | | Replacement | | Original | Replacement |
|---|----------|---|-------|----------|-------------|
|  | Page+ |  | Ch + | | |
|  | Page- |  | Ch - | | |
|  | 1 |  | 1 | | |
|  | 2 |  | 2 | | |
|  | 3 |  | 3 | | |
|  | 4 |  | 4 | | |
|  | 5 |  | 5 | | |
|  | 6 |  | 6 | | |
|  | 7 |  | 7 | | |
|  | 8 |  | 8 | | |
|  | 9 |  | 9 | | |
|  | 0 |  | 0 | | |
|  | Sleep |  | Sleep | | |
|  | TV/Radio |  | TV/R | | |
| | | | | | |
| | | | | | |
| | | | | | |

