



Original	Replacement
Power	Power
Mute	Mute
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Vol+	Vol +
Vol-	Vol -
Prog+	Ch +
Prog-	Ch -
Up	Up

Original	Replacement
OK	Ok
Down	Down
Left	Left
Right	Right
Menu	Menu
Return	Back
Tv/Radio	TV/R
O)/A-B	Dual
List	List

