
















Original	Replacement	Original	Replacement
 Standby	 Power	 Right	 Right
 Rec PVR	 Rec	 Left	 Left
 PVR List	 List	 OK	 Ok
 Mute	 Mute	 Vol+	 Vol +
 EPG	 Guide	 Vol-	 Vol -
 Audio	 Dual	 1	 1
 Info	 Info	 2	 2
 TTX	 Text	 3	 3
 Subtitle	 Subt	 4	 4
 Menu	 Menu	 5	 5
 Exit	 Exit	 6	 6
 Favourite	 Pre Ch	 7	 7
 Tv/Radio	 TV/R	 8	 8
 CH+	 Ch +	 9	 9
 CH-	 Ch -	 0	 0
 Up	 Up	 Recall	 Back
 Down	 Down	 Goto	 AV





	Original	Replacement	Original	Replacement
	<<			<<
	>>			>>
	<<			<<
	>>			>>
	Play			Play
	Pause			Pause
	Stop			Stop
	Repeat	 + 		Shift + Text
	Red			Red
	Green			Green
	Yellow			Yellow
	Blue			Blue

