







































































Original	Replacement	Original	Replacement
 Power	 Power	 [i+]/[?]	 Info
 Mute	 Mute	 Red	 Red
 []	 TV/R	 Green	 Green
 Sound	 Dual	 Yellow	 Yellow
 *	 Options	 Blue	 Blue
 Source	 AV	 [≡]/Text	 Text
 [X]	 Format	 -/--/Recall	 Pre Ch
 1	 1	 Guide	 Guide
 2	 2	 Up	 Up
 3	 3	 OK	 Ok
 4	 4	 Down	 Down
 5	 5	 Right	 Right
 6	 6	 Left	 Left
 7	 7	 Prog+	 Ch +
 8	 8	 Prog-	 Ch -
 9	 9	 Vol+	 Vol +
 0	 0	 Vol-	 Vol -





Original	Replacement
Menu	Menu
[+]	3D
≡	Smart
Power	Shift + Power
1 AUX/Video	Shift + 1
2 AUX/Video	Shift + 2
3 AUX/Video	Shift + 3
4 AUX/Video	Shift + 4
5 AUX/Video	Shift + 5
6 AUX/Video	Shift + 6
7 AUX/Video	Shift + 7
8 AUX/Video	Shift + 8
9 AUX/Video	Shift + 9
0 AUX/Video	Shift + 0
--- AUX/Video	Shift + Pre Ch
Up AUX/Video	Shift + Up
Down	Shift + Down

Original	Replacement
Right	Shift + Right
Left AUX/Video	Shift + Left
OK AUX/Video	Shift + Ok
Prog+	Shift + Ch +
Prog-	Shift + Ch -
Rec AUX/Video	Rec



AUX/Video