



Original	Replacement
Power	Power
OPC	D.Menu / Top
Sleep	Sleep / Timer
Dual Screen	Shift + Red / Netflix /
Select	Shift + Green / APP /
[i+]	Info / Angle
Aspect	Picture / Format
Dual Screen Size	Shift + Yellow / YouTube /
AV Mode	Display / Media
Rotate	Setup / OPT /
Dolby Virtual	Smart / List
3D-Y/C	Shift + 3
1	1
2	2
3	3
4	4
5	5

Original	Replacement
6	6
7	7
8	8
9	9
Recall	Back / Return
0	0
-/--	Guide / EPG / -/--
[...]	Subtitle / EQ
[≡?]	Play / Slow
[≡i]	Pause / Step / Freeze
[≡]	Text / Goto
Sound	Sound / Title
Vol+	Vol+
P+	CH+ / Page+
Mute	Mute / Dimmer
Vol-	Vol-
P-	CH- / Page-





Original	Replacement
	Input / RDS
	Menu / Home
	Up
	Left
	OK
	Right
	Exit / Cancel / Clear
	Down
	+  Shift + Back / Return
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random

Original	Replacement

