







































































Original		Replacement		Original		Replacement	
	Power		Power		Vol+		Vol +
	Input		AV		Vol-		Vol -
	Home		Shift + Smart		CH+		Ch +
	YouTube		Smart		CH-		Ch -
	1		1		Q.View		Options
	2		2		Guide		Guide
	3		3		Menu		Menu
	4		4		Return		Back
	5		5		Exit		Exit
	6		6		3D		3D
	7		7		CH.List		List
	8		8		MTS/SAP		Dual
	9		9		CC		Subt
	0		0		Q.Menu		D. Menu
	FAV		Pre Ch		OK		Ok
	Mute		Mute		Up		Up
	Info		Info		Down		Down





Original	Replacement	Original	Replacement
	Right		Right
	Left		Left
	Sleep		Sleep
	S.Mode		Shift + Dual
	USB		Media
	P.Mode		Shift + Format
	H.Lock		Shift + Stop
	P.Size		Format
	Red		Red
	Play		Play
	Pause		Pause
	Green		Green
	<<		<<
	Yellow		Yellow
	>>		>>
	Blue		Blue
	Stop		Stop

