






























































Original	Replacement	Original	Replacement
	Power		Power
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Stop		Stop / Hold
	<< Search		<< / Tune-
	Search >>		>> / Tune+
	I<< Skip		I<< / Preset-
	Skip >>I		>>I / Preset+
	Re-Master		Sound / Title
	Audio		Audio / Lang I/II
	Open/Close		Eject / Surround
	PIP		Picture / Format
	Select/Drive		D.Menu / Top
	Option		Setup / OPT /
	Cast/Vieta		Text / Goto
	AV Tv		AV / Input / RDS
	Function Menu		Menu / Home
	Up		Up
	Left/<II		Left
	OK		OK
	Right/II>		Right
	Exit		Exit / Cancel / Clear
	Down		Down
	Return		Back / Return
	Vol+ Tv		Vol+
	Top Menu/Direct Navigator		Smart / List
	CH+ Tv		CH+ / Page+
	Vol- Tv		Vol-
	Display		Display / Media
	CH- Tv		CH- / Page-
	1		1
	2		2
	3		3
	4		4





	Original	Replacement	Original	Replacement
	5			
	6			
	7			
	8			
	9			
	0			
	Red			Red / Netflix / Search
	Green			Green / APP / Repeat
	Yellow			Yellow / YouTube / Repeat
	Blue			Blue / Prime Video / Random
	Power Tv			Shift + Power
	Status			Shift + Setup / OPT / Tools
	Cancel			Shift + Exit / Cancel / Clear
	Vol+ Receiver			Shift + Vol+
	Pop-Up Menu			Shift + Smart / List
	Vol- Receiver			Shift + Vol-

