



| Original   | Replacement   |
|--|---|
|  Power    |  Power           |
|  Mute     |  Mute            |
|  1        |  1               |
|  2        |  2               |
|  3        |  3               |
|  4        |  4               |
|  5        |  5               |
|  6        |  6               |
|  7        |  7               |
|  8       |  8              |
|  9      |  9             |
|  0      |  0             |
|  -/--   |  Shift + Guide |
|  Recall |  Pre Ch        |
|  Vol+   |  Vol +         |
|  Vol-   |  Vol -         |
|  Nicam  |  Smart         |

| Original  | Replacement   |
|---|---|
|  DVB Menu    |  Media   |
|  CH+         |  Ch +    |
|  CH-         |  Ch -    |
|  Menu        |  Menu    |
|  Back        |  Back    |
|  Up          |  Up      |
|  Down        |  Down    |
|  Right       |  Right   |
|  Left        |  Left    |
|  OK         |  Ok     |
|  AV/TV     |  AV    |
|  EPG       |  Guide |
|  SUBT      |  Subt  |
|  i/Info    |  Info  |
|  [≡]/Text  |  Text  |
|  [≡+]/Hold |  Dual  |
|  [▼]/PGDN  |  <<    |



