





































Original	Replacement	Original	Replacement
On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Update	 +  Shift + Media	Menu Off	 Exit
Reveal	 Options	Menu Down	 Down
Txt Stop	 Stop	Back	 Back
Info	 Info	Volume+	 Vol +
Subt.List	 Subt	Chan.Up	 Ch +
Sleep Timer	 Sleep	Volume-	 Vol -
Return TV	 TV/R	Menu audio	 Dual
Menu video	 D. Menu	Chan.Down	 Ch -
Text	 Text	1	 1
Txt Expand	 Eject	2	 2
TV/AV	 AV	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Display	 +  Shift + Info	6	 6
Menu Left	 Left	7	 7



Original	Replacement	Original	Replacement
8	 8	Store Text	 +  Shift + Text
9	 9	Audio+	 +  Shift + Vol +
Guide -/-- 1.	 Guide	Audio-	 +  Shift + Vol -
0/10	 0	AV 2	 +  Shift + AV
2.Fav P/C 2.	 Pre Ch	Bright+ Mode	 +  Shift + Menu
Red	 Red	Disp	 +  Shift + Options
Green	 Green	Color- S.Std	 Media
Mix Scan	 +  Shift + 3D	Search	 +  Shift + TV/R
Yellow	 Yellow	Store	 Rec
Blue	 Blue	Contrast+	 +  Shift + Ch +
Rotate Text	 List	Browse	 3D
Off/Tim	 +  Shift + Down	Contrast-	 +  Shift + Ch -
On/Tim	 +  Shift + Up	On Pip	 +  Shift + 1
Tone-	 +  Shift + Left	Swap	 +  Shift + 2
Color+ P.Std	 +  Shift + D. Menu	4.# 16:9	 Format
Tone+	 +  Shift + Right	Still	 +  Shift + 4
Game Coo	 Smart	Dim Pip	 +  Shift + 5



Original	Replacement	Original	Replacement
3.*	 +  Shift + Guide		
View	 +  Shift + 0		
Surround	 +  Shift + Red		
Nicam/Mono	 +  Shift + Green		
Level L	 +  Shift + Yellow		
Level R/Woofers	 +  Shift + Blue		

