



Original		Replacement		Original		Replacement	
	Power		Power		Page Up		Shift + Up
	Resync		+ / Play		Page Down		Shift + Down
	Source		Source		1/RGB		Shift + Vol + / Page +
	Freeze		Freeze / Timer		2/Brightness		Shift + + / Play
	Hide		Volt / Focus		3/Color		Shift + Volt / Focus
	Aspect/Ratio		Eco / Aspect		4/VGA		Shift + Vol - / Page -
	PIP		Auto		5/Component		Shift + - / Stop
	Zoom		3D / Invert		6/Video		Shift + Help / Info
	Location		- / Stop		7/DVI		Shift + Eco / Aspect
	Up		Up		8/HDMI		Shift + 3D / Invert
	Down		Down		9/Wireless		Shift + Blank / Mute
	Right		Right		0/Mute		Blank / Mute
	Left		Left		Contrast		Mode
	Menu		Menu		S-Video		Comp / Video
	Vol+		Vol + / Page +				
	Vol-		Vol - / Page -				
	e		Help / Info				

