











































































































































Original	Replacement	Original	Replacement
 Power	 Power	 Up	 Up
 Input TV	 Red	 Left	 Left
 Input DVD/BD	 Green	 OK	 Ok
 Input SAT	 Yellow	 Right	 Right
 Input AUDIO	 Blue	 Down	 Down
 1	 1	 Return	 Back
 2	 2	 Options	 Options
 3	 3	 I<<	 I<<
 4	 4	 ←	 Shift + I<<
 5	 5	 →	 Shift + >>I
 6	 6	 >>I	 >>I
 7	 7	 <<	 <<
 8	 8	 Play	 Play
 9	 9	 >>	 >>
 0	 0	 Pause	 Pause
 -/--	 Guide	 Stop	 Stop
 Enter	 Pre Ch	 Sound Field	 Dual





































































Original	Replacement	Original	Replacement
 TV Power	 Power	 Hold	 Shift + Stop
 Input	 AV	 Red	 Red
 1	 1	 Green	 Green
 2	 2	 Yellow	 Yellow
 3	 3	 Blue	 Blue
 4	 4	 Guide	 Guide
 5	 5	 i+	 Info
 6	 6	 Up	 Up
 7	 7	 Left	 Left
 8	 8	 OK	 Ok
 9	 9	 Right	 Right
 0	 0	 Down	 Down
 Text	 Text	 Return	 Back
 Recall	 Pre Ch	 Menu	 Menu
 Analog	 Shift + TV/R	 Tools	 Options
 Digital	 TV/R	 << / <   / <	 <<
 Aspect	 Format	 Play	 Play







Original	Replacement	Original	Replacement
 Power	 Power	 Down	 Down
 1	 1	 Return	 Back
 2	 2	 I<<	 I<<
 3	 3	 >>I	 >>I
 4	 4	 <<	 <<
 5	 5	 Play	 Play
 6	 6	 >>	 >>
 7	 7	 Pause	 Pause
 8	 8	 Stop	 Stop
 9	 9	 Prog+	 Ch +
 0	 0	 Prog-	 Ch -
 Recall	 Pre Ch	 Rec	 Rec
 [i+]/[?]	 Info	 DVD Top Menu	 Menu
 Up	 Up	 DVD Menu	 D. Menu
 Left	 Left		
 OK	 Ok		
 Right	 Right		



