







































































| Original  | Replacement   | Original   | Replacement   |
|---|---|--|---|
|  Power     |  Power       |  --       |  Guide / EPG / -/--            |
|  Up / P+   |  Up          |  0        |  0                             |
|  Up / P+   |  CH+ / Page+ |  P < P    |  Fav / Marker / PC             |
|  Menu      |  Menu / Home |  PP       |  Back / Return                 |
|  Left      |  Left        |  Vol+     |  Vol+                          |
|  Right     |  Right       |  I-II     |  Audio / Lang I/II             |
|  Down / P- |  Down        |  Mute     |  Mute / Dimmer                 |
|  Down / P- |  CH- / Page- |  Vol-     |  Vol-                          |
|  1         |  1           |  Info     |  Info / Angle                  |
|  2        |  2          |  Red     |  Red / Netflix / Search       |
|  3       |  3         |  Green  |  Green / APP / Repeat        |
|  4       |  4         |  Yellow |  Yellow / YouTube / Repeat   |
|  5       |  5         |  Blue   |  Blue / Prime Video / Random |
|  6       |  6         |  [TV]   |  Shift + 1                   |
|  7       |  7         |  [TV]   |  TV/Radio /                  |
|  8       |  8         |  [AV]   |  AV / Input / RDS            |
|  9       |  9         |  [ ≡ ]  |  Text / Goto                 |









































































| Original  |       | Replacement   |                       | Original | Replacement |
|---|-------|---|-----------------------|----------|-------------|
|  | [≡⊕]  |  SUBTITLE          | Subtitle / EQ         |          |             |
|  | [ /≡] |  FORMAT PICTURE    | Picture / Format      |          |             |
|  | [≡X]  |  CLEAR EXIT CANCEL | Exit / Cancel / Clear |          |             |
|  | [≡⇕]  |  SIZE ZOOM         | Zoom / Size           |          |             |
|  | [≡?]  |  MEDIA DISPLAY     | Display / Media       |          |             |
|  | [≡i]  |  LIST SMART        | Smart / List          |          |             |
|   |       |   |                       |          |             |
|   |       |   |                       |          |             |
|   |       |   |                       |          |             |
|   |       |   |                       |          |             |
|   |       |   |                       |          |             |
|   |       |   |                       |          |             |
|   |       |   |                       |          |             |
|   |       |   |                       |          |             |
|   |       |   |                       |          |             |
|   |       |   |                       |          |             |
|   |       |   |                       |          |             |
|   |       |   |                       |          |             |
|   |       |   |                       |          |             |
|   |       |   |                       |          |             |
|   |       |   |                       |          |             |
|   |       |   |                       |          |             |





| Original  | Replacement | Original  | Replacement                 |
|---|-------------|---|-----------------------------|
|      | Power       |      | Power                       |
|      | Up / P+     |      | Up                          |
|      | Up / P+     |      | CH+ / Page+                 |
|      | Menu        |      | Menu / Home                 |
|      | Left        |      | Left                        |
|      | Select      |      | OK                          |
|      | Right       |      | Right                       |
|      | Down / P-   |      | CH- / Page-                 |
|      | Down / P-   |      | Down                        |
|     | 1           |     | 1                           |
|    | 2           |    | 2                           |
|    | 3           |    | 3                           |
|    | 4           |    | 4                           |
|    | 5           |    | 5                           |
|    | 6           |    | 6                           |
|    | 7           |    | 7                           |
|    | 8           |    | 8                           |
|    | 9           |    | 9                           |
|    | +10         |    | Guide / EPG / -/--          |
|    | 0           |    | 0                           |
|    | Repeat      |    | Green / APP / Repeat        |
|    | Search      |    | Red / Netflix / Search      |
|    | A→B         |    | Yellow / YouTube / Repeat   |
|    | Display     |    | Display / Media             |
|    | Audio       |    | Audio / Lang I/II           |
|    | Subtitle    |    | Subtitle / EQ               |
|   | Zoom        |   | Zoom / Size                 |
|  | Prog        |  | TV/Radio /                  |
|  | C           |  | Blue / Prime Video / Random |
|  | Angle       |  | Info / Angle                |
|  | Return      |  | Back / Return               |
|  | Time        |  | Sleep / Timer               |
|  | <<          |  | << / Tune-                  |
|  | >>          |  | >> / Tune+                  |









































































| Original   | Replacement   |
|--|---|
|               |   << / Preset-         |
|               |  >>  / Preset+         |
|               |  Play / Slow           |
|               |  Pause / Step / Freeze |
|               |  Stop / Hold           |
|  Title        |  Sound / Title         |
|  Open / Close |  Eject / Surround      |
|  |   |
|  |   |
|  |   |
|  |   |
|  |   |
|  |   |
|  |   |
|  |   |
|  |   |
|  |   |
|  |   |
|  |   |
|  |   |
|  |   |
|  |   |
|  |   |

| Original | Replacement |
|----------|-------------|
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |





| Original    | Replacement   | Original   | Replacement   |
|-------------|---|------------|---|
| On/Off      |  Power             | Menu Right |  Right           |
| Mute        |  Mute / Dimmer     | Menu Down  |  Down            |
| Txt Stop    |  Stop / Hold       | Back       |  Back / Return   |
| Tone+       |  >> / Tune+        | Volume+    |  Vol+            |
| Lang        |  Sound / Title     | Chan.Up    |  CH+ / Page+     |
| Menu audio  |  Audio / Lang I/II | Volume-    |  Vol-            |
| Subt.List   |  Subtitle / EQ     | Display    |  Display / Media |
| Txt Expand  |  Zoom / Size       | Chan.Down  |  CH- / Page-     |
| Sleep Timer |  Sleep / Timer     | 1          |  1               |
| Return TV   |  TV/Radio /        | 2          |  2               |
| Menu video  |  D.Menu / Top      | 3          |  3               |
| Text        |  Text / Goto      | 4          |  4              |
| Menu        |  Menu / Home     | 5          |  5             |
| Menu Up     |  Up              | 6          |  6             |
| Info        |  Info / Angle    | 7          |  7             |
| Menu Left   |  Left            | 8          |  8             |
| OK Enter    |  OK              | 9          |  9             |

| Original    | Replacement   | Original   | Replacement   |
|-------------|---|------------|---|
| On/Off      |  Power             | Menu Right |  Right           |
| Mute        |  Mute / Dimmer     | Menu Down  |  Down            |
| Txt Stop    |  Stop / Hold       | Back       |  Back / Return   |
| Tone+       |  >> / Tune+        | Volume+    |  Vol+            |
| Lang        |  Sound / Title     | Chan.Up    |  CH+ / Page+     |
| Menu audio  |  Audio / Lang I/II | Volume-    |  Vol-            |
| Subt.List   |  Subtitle / EQ     | Display    |  Display / Media |
| Txt Expand  |  Zoom / Size       | Chan.Down  |  CH- / Page-     |
| Sleep Timer |  Sleep / Timer     | 1          |  1               |
| Return TV   |  TV/Radio /        | 2          |  2               |
| Menu video  |  D.Menu / Top      | 3          |  3               |
| Text        |  Text / Goto      | 4          |  4              |
| Menu        |  Menu / Home     | 5          |  5             |
| Menu Up     |  Up              | 6          |  6             |
| Info        |  Info / Angle    | 7          |  7             |
| Menu Left   |  Left            | 8          |  8             |
| OK Enter    |  OK              | 9          |  9             |





| Original      | Replacement              |                             |
|---------------|--------------------------|-----------------------------|
| Guide -/-- 1. | GUIDE EPG                | Guide / EPG / -/--          |
| 0/10          | HDMI - SAT 0             | 0                           |
| 2.Fav P/C 2.  | PC FAV MARKER            | Fav / Marker / PC           |
| Red           | NETFLIX SEARCH           | Red / Netflix / Search      |
| Green         | APP REPEAT               | Green / APP / Repeat        |
| Yellow        | YouTube REPEAT A-B       | Yellow / YouTube / Repeat   |
| Blue          | Prime Video RANDOM       | Blue / Prime Video / Random |
| Lang          | SHIFT +  LANG I/II AUDIO | Shift + Audio / Lang I/II   |
|               |                          |                             |
|               |                          |                             |
|               |                          |                             |
|               |                          |                             |
|               |                          |                             |
|               |                          |                             |
|               |                          |                             |
|               |                          |                             |
|               |                          |                             |
|               |                          |                             |
|               |                          |                             |
|               |                          |                             |

| Original | Replacement |
|----------|-------------|
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |

