





































































Original	Replacement	Original	Replacement
 Power	 Power	 Blue	 Blue
 Mute	 Mute	 TV / DTV	 Smart
 1	 1	 Menu	 Menu
 2	 2	 Up	 Up
 3	 3	 Left	 Left
 4	 4	 OK	 Ok
 5	 5	 Right	 Right
 6	 6	 Down	 Down
 7	 7	 Guide	 Guide
 8	 8	 Back	 Back
 9	 9	 P-	 Ch -
 0	 0	 P+	 Ch +
 i	 Info	 Vol+	 Vol +
 AV	 AV	 Vol-	 Vol -
 Red	 Red	 I/II	 Dual
 Green	 Green	 OO	 Shift + Dual
 Yellow	 Yellow	 TV / Radio	 TV/R





































	Original	Replacement	Original	Replacement
	Colour System	Options		
	Sleep Timer	Sleep		
	[...]	Subt		
	Zoom	Eject		
	[≡]	Text		
	[≡i]	List		
	[?]	D. Menu		
	[↕]	Format		
	[⊖]	+ Shift + Subt		





	Original	Replacement	Original	Replacement
	Power			
	Menu			
	Back			
	OK			
	Up			
	Down			
	Right			
	Left			
	<<			
	Play			
	>>			
	Stop			
	Pause			
	Rec / Top Menu			
	↑			
	↓			





	Original	Replacement	Original	Replacement
	Power			
	<<			
	Play			
	>>			
	Rec			
	Pause			
	Stop			
	Up			
	Down			

