






































Original		Replacement		Original		Replacement	
	Power		Power		FAV		Fav / Marker / PC
	Mute		Mute / Dimmer		PG+		CH+ / Page+
	TV / STB		Shift + TV/Radio / Program		PG-		CH- / Page-
	TV / Radio		TV/Radio /		Vol+		Vol+
	DVR Info		Shift + Info / Angle		Vol-		Vol-
	SAT List		Smart / List		M / P		D.Menu / Top
	1		1		Up		Up
	2		2		EPG		Guide / EPG / -/-
	3		3		Left		Left
	4		4		OK		OK
	5		5		Right		Right
	6		6		Menu		Menu / Home
	7		7		Down		Down
	8		8		Exit		Exit / Cancel / Clear
	9		9		Info		Info / Angle
	Audio		Audio / Lang I/II		V-Format		Picture / Format
	0		0		Recall		Back / Return





	Original	Replacement	Original	Replacement
		Zoom		Zoom / Size
		Red		Red / Netflix / Search
		Green		Green / APP / Repeat
		Yellow		Yellow / YouTube / Repeat
		Blue		Blue / Prime Video / Random
		◀◀ FB		<< / Tune-
		▶▶ FF		>> / Tune+
		◀◀ REV Slow		Shift + << /
		▶▶ Slow		Shift + >> /
		● Record		Rec / Rec Mode
		▶ Play		Play / Slow
		Pause		Pause / Step / Freeze
		■ Stop		Stop / Hold
		Find		Shift + Red / Netflix /
		Subtitle		Subtitle / EQ
		Sleep		Sleep / Timer
		Text		Text / Goto

