










































































































Original	Replacement	Original	Replacement
 Power	 Power	 Exit	 Exit
 Mute	 Mute	 Up	 Up
 1	 1	 Left	 Left
 2	 2	 OK	 Ok
 3	 3	 Right	 Right
 4	 4	 Down	 Down
 5	 5	 CH+	 Ch +
 6	 6	 CH-	 Ch -
 7	 7	 Page+	 Shift + Ch +
 8	 8	 Page-	 Shift + Ch -
 9	 9	 Vol+	 Vol +
 0	 0	 Vol-	 Vol -
 TV / Rad	 TV/R	 Red / Sub	 Red
 Format	 Format	 Red / Sub	 Subt
 Menu	 Menu	 Green / Audio	 Green
 Guide	 Guide	 Green / Audio	 Dual
 Back	 Back	 Yellow / Info	 Yellow

Original	Replacement	Original	Replacement
 MUTE	 MUTE	 SHIFT	 SHIFT
 TV	 TV	 DVD	 AUX
 DVD	 DVD	 SAT	 REC MODE
 SAT	 SAT	 PLAY MODE	 PLAY MODE
 AUX	 AUX	 PAUSE	 PAUSE
 PLAY MODE	 PLAY MODE	 STOP	 STOP
 PAUSE	 PAUSE	 FF	 FF
 STOP	 STOP	 FR	 FR
 FF	 FF	 DISC NAV	 DISC NAV
 FR	 FR	 SOUND	 AD
 DISC NAV	 DISC NAV	 SETTINGS	 SETTINGS
 SOUND	 SOUND	 LIST	 LIST
 SETTINGS	 SETTINGS	 DUAL	 SUBT
 LIST	 LIST	 PROG	 PROG
 DUAL	 DUAL	 SEARCH	 SEARCH
 SUBT	 SUBT	 PICTURE	 PICTURE
 PROG	 PROG	 ECO	 ECO
 SEARCH	 SEARCH	 SLEEP	 SLEEP
 PICTURE	 PICTURE	 TV/R	 TV/R
 ECO	 ECO	 FORMAT	 FORMAT
 SLEEP	 SLEEP	 3D	 3D
 TV/R	 TV/R	 E-MANUAL	 E-MANUAL
 FORMAT	 FORMAT	 REPEAT	 REPEAT
 3D	 3D	 ZOOM	 ZOOM
E-MANUAL	E-MANUAL	TIMER	TIMER
REPEAT	REPEAT	AV	AV
ZOOM	ZOOM		
TIMER	TIMER		
AV	AV		
		 TOP MENU	 TOP MENU
		 INFO	 INFO
		 MENU	 MENU
		 OK	 OK
		 RETURN	 RETURN
		 CLEAR	 CLEAR
		 EXIT	 EXIT
		 HOME	 HOME
		 SMART	 SMART
		 APP	 APP
		 MEDIA	 MEDIA
		 VOL +	 VOL +
		 VOL -	 VOL -
		 1	 1
		 2	 2
		 3	 3
		 4	 4
		 5	 5
		 6	 6
		 7	 7
		 8	 8
		 9	 9
		 0	 0
		 FR	 FR
		 FF	 FF
		 GUIDE	 GUIDE
		 PRE-CH	 PRE-CH
		 A	 A
		 B	 B
		 C	 C
		 D	 D
			
			





Original		Replacement		Original	Replacement
	Yellow / Info		Info		
	Blue / TXT		Blue		
	Blue / TXT		Text		
	FAV		Pre Ch		
	Pause		Pause		
	Aspect	 + 	Shift + Format		
	DVR		Smart		
	Rec		Rec		
	Stop		Stop		
	<<		<<		
	>>		>>		
	Play		Play		
	<<		<<		
	>>		>>		
	Scan		Media		

