















Original	Replacement
	Power
	Mute
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	-/--
	AV
	Menu
	Swap
	OK

Original	Replacement
	Up
	PR+
	PR-
	Down
	Right
	Vol+
	Left
	Vol-
	TV/TX
	PP
	16:9
	Red
	Green
	Yellow
	Blue
	Violet
	[] Smart Controls



