



Original	Replacement	Original	Replacement
Power	Power	PC	Media
Source	AV	Mute	Mute
1	1	Vol+	Vol +
2	2	Vol-	Vol -
3	3	P+	Ch +
4	4	P-	Ch -
5	5	Menu	Menu
6	6	Exit	Exit
7	7	Up	Up
8	8	Down	Down
9	9	Right	Right
0	0	Left	Left
TV	Guide	Enter	Ok
CH.MGR	Pre Ch	[≡+]/PIP	3D
Sleep	Sleep	[≡?]/Info	Info
		[≡]/[ /≡]/TTX/MIX	Text
		Red-/I/I-/P.Mode	Red

Original	Replacement	Original	Replacement
Power	Power	PC	Media
Source	AV	Mute	Mute
1	1	Vol+	Vol +
2	2	Vol-	Vol -
3	3	P+	Ch +
4	4	P-	Ch -
5	5	Menu	Menu
6	6	Exit	Exit
7	7	Up	Up
8	8	Down	Down
9	9	Right	Right
0	0	Left	Left
TV	Guide	Enter	Ok
CH.MGR	Pre Ch	[≡+]/PIP	3D
Sleep	Sleep	[≡?]/Info	Info
		[≡]/[ /≡]/TTX/MIX	Text
		Red-/I/I-/P.Mode	Red





Original	Replacement	Original	Replacement
Green/-I-I-/S.Mod e	Green		
Yellow/Still	Yellow		
Blue/P.Size	Blue		
[≡♦]/Source	+  Shift + AV		
[≡◇]/Swap	Options		
Size	Format		
I-II/Dual	Dual		
(o)/SRS	Subt		
[←]/Position	Smart		
P Up	>>		
P Down	<<		

