













































Original	Replacement
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 Guide
 Cancel	 Exit
 AV	 AV
 Input Select	 Media
 Direct Tv Rec	 TV/R
 ShowView	 3D

Original	Replacement
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 I<< Skip	 I<<
 Skip >>I	 >>I
 << Slow/Search	 <<
 Slow/Search >>	 >>
 Pause	 Pause
 Stop	 Stop
 Play	 Play
 Menu/Play List	 Menu
 Top Menu / Direct Navigator	 D. Menu
 Functions	 Options
 Return	 Back
 Up	 Up
 Down	 Down









































Original	Replacement
	 Right
	 Left
	 Ok
	 Rec
	 +  Shift + Right
	 +  Shift + Left
	 Format
	 Text
	 Sleep
	 Smart
	 +  Shift + AV
	 Pre Ch
	 List
	 +  Shift + Rec
	 Subt
	 Red
	 Info

Original	Replacement
	 Green
	 Yellow
	 Dual
	 Blue





Original	Replacement
 Power	 Power
 CH+	 Ch +
 CH-	 Ch -
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 Guide
 A	 Red
 B	 Green
 C	 Yellow

Original	Replacement
 D	 Blue

