





































Original	Replacement	Original	Replacement
On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Update	 List	Menu Off	 Exit
Reveal	 +  Shift + List	Menu Down	 Down
Txt Stop	 Stop	Back	 Back
Info	 Info	Volume+	 Vol +
Subt.List	 Subt	Chan.Up	 Ch +
Sleep Timer	 Sleep	Menu audio	 Dual
Return TV	 TV/R	Volume-	 Vol -
Menu video	 D. Menu	Chan.Down	 Ch -
Text	 Text	1	 1
Txt Expand	 Eject	2	 2
TV/AV	 AV	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Display	 +  Shift + Info	6	 6
Menu Left	 Left	7	 7



Original	Replacement	Original	Replacement
8	 8	Store Text	 Shift + Text
9	 9	Search	 Shift + TV/R
Guide -/-- 1.	 Guide	Tone+	 Shift + Up
0/10	 0	Store	 Smart
2.Fav P/C 2.	 Pre Ch	Browse	 Media
Red	 Red	Tune-	 Shift + Left
On/Tim	 Options	Color- S.Std	 Shift + Dual
Mix Scan	 Play	Aft/Caf	 Shift + Ok
Bright+ Mode	 >>	Tone-	 Shift + Down
Green	 Green	Tune+	 Shift + Right
Rotate Text	 >>	Contrast+	 Shift + Ch +
Audio+	 3D	Contrast-	 Shift + Ch -
Disp	 Format	3.*	 Shift + Guide
Yellow	 Yellow	Surround	 Shift + Red
Bright- Sys	 I<<	Nicam/Mono	 Shift + Green
Blue	 Blue	Level L	 Shift + Yellow
Color+ P.Std	 Shift + Format	Level R/Woofer	 Shift + Blue

