



































Original	Replacement	Original	Replacement
On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Update	 Smart	Menu Off	 Exit
Reveal	 Media	Menu Down	 Down
Txt Stop	 Stop	Back	 Back
Info	 Info	Volume+	 Vol +
Subt.List	 Subt	Chan.Up	 Ch +
Sleep Timer	 Sleep	Volume-	 Vol -
Return TV	 TV/R	Menu audio	 Dual
Menu video	 D. Menu	Chan.Down	 Ch -
Text	 Text	1	 1
Txt Expand	 Eject	2	 2
TV/AV	 AV	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Display	 Shift + Info	6	 6
Menu Left	 Left	7	 7



Original	Replacement	Original	Replacement
8	 8	Tone-	 I<<
9	 9	Tune-	 +  Shift + Left
Guide -/-- 1.	 Guide	Aft/Caf	 +  Shift + Ok
0/10	 0	Tune+	 +  Shift + Right
2.Fav P/C 2.	 Pre Ch	Bright- Sys	 +  Shift + Exit
Red	 Red	Contrast+	 +  Shift + Ch +
Green	 Green	Contrast-	 +  Shift + Ch -
Yellow	 Yellow	Color- S.Std	 +  Shift + Dual
Mix Scan	 Options	3.*	 +  Shift + Guide
On/Tim	 List	4.# 16:9	 Format
Off/Tim	 +  Shift + List	Surround	 +  Shift + Red
Blue	 Blue	Nicam/Mono	 +  Shift + Green
Tone+	 >>I	Level L	 +  Shift + Yellow
Disp	 3D	Level R/Woofer	 +  Shift + Blue
Audio-	 <<		
Color+ P.Std	 +  Shift + Format		
Audio+	 >>		

