



	Original	Replacement		Original	Replacement
	Power	 Power			
	Input	 Source			
	Mute	 Blank / Mute			
	Menu	 Menu			
	Up	 Up			
	Down	 Down			
	Right/Bright+	 Right			
	Left/Bright-	 Left			
	Enter	 Enter			
	Vol+	 Vol + / Page +			
	Vol-	 Vol - / Page -			
	Return	 3D / Invert			
	Display	 Auto			
	Mode	 Mode			
	Size	 Eco / Aspect			

