







































































Original		Replacement		Original		Replacement	
	Power		Power		3		3
	Mute		Mute		4		4
	Play		Play		5		5
	[≡]		Text		6		6
	Pause/[ /≡]		Pause		7		7
	Stop/[≡+]		Stop		8		8
	Rec/[≡◆]		Rec		9		9
	<</[≡o]		<<		0		0
	l<</[≡i]		l<<		Menu		Menu
	>>/[≡?]		>>l		Exit		Exit
	>>/[≡x]		>>		Up		Up
	Info		Info		Left		Left
	EPG		Guide		OK		Ok
	Subtitle		Subt		Right		Right
	Audio		Dual		Down		Down
	1		1		Back		Back
	2		2		Home/Source		Smart



