



































Original	Replacement	Original	Replacement
PWR On/Off	 Power		
Mute	 Mute / Dimmer		
App	 Shift + Green / APP /		
Info	 Info / Angle		
Subt.List	 Subtitle / EQ		
TV	 TV/Radio /		
Video	 Shift + 4		
Text	 Text / Goto		
Zoom	 Zoom / Size		
Menu	 Menu / Home		
TV/SAT	 AV / Input / RDS		
Menu Up	 Up		
Display	 Display / Media		
Menu Left	 Left		
OK Enter	 OK		
Menu Right	 Right		
Exit	 Exit / Cancel / Clear		

Original	Replacement	Original	Replacement
Menu Down	 Down		
Back	 Back / Return		
Volume+	 Vol+		
CH/Page+	 CH+ / Page+		
Volume-	 Vol-		
Audio	 Audio / Lang I/II		
CH/Page-	 CH- / Page-		
1. ?	 1		
2abc	 2		
3def	 3		
4ghi	 4		
5jkl	 5		
6mno	 6		
7pqrm	 7		
8tuv	 8		
9wxyz	 9		
Guide Pilote	 Guide / EPG / -/-		



Original	Replacement	Original	Replacement
0/10	 0		
FAV Pref.	 Fav / Marker / PC		
Red	 Red / Netflix / Search		
Green	 Green / APP / Repeat		
Yellow	 Yellow / YouTube / Repeat		
Blue	 Blue / Prime Video / Random		
Dec/Pause	 Pause / Step / Freeze		
SAT Sky	 Smart / List		
	 >>  / Preset+		
	  << / Preset-		

