





































| Original | Replacement |
|--|---|
|  Power |  Power |
|  TV/AV |  AV |
|  Mute |  Mute |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  -/-- |  Guide |
|  Recall |  Back |
|  Vol+ |  Vol + |
|  Vol- |  Vol - |

| Original | Replacement |
|--|--|
|  A1 (no name) |  Shift + 1 |
|  A2 (no name) |  Shift + 2 |
|  B2 (no name) |  Shift + 3 |
|  CH+ |  Ch + |
|  CH- |  Ch - |
|  Up |  Up |
|  Left |  Left |
|  OK |  Ok |
|  Right |  Right |
|  Down |  Down |
|  Menu |  Menu |
|  Exit |  Exit |
|  Picture |  Shift + Format |
|  Sound |  Shift + Dual |
|  Sleep |  Sleep |
|  Display |  Info |
|  Eject/Aspect |  Format |





| Original | Replacement |
|---|--|
|  Eject/Aspect |  Eject |
|  FAV |  Pre Ch |
|  Play |  Play |
|  Pause |  Pause |
|  Stop/Nicam/A2 |  Stop |
|  Goto/Auto |  Media |
|  Setup |  Options |
|  Title |  List |
|  Angle |  3D |
|  Audio |  Dual |
|  D.Menu/Text |  Text |
|  D.Menu/Text |  D. Menu |
|  D.Switch/Hold |  Smart |
|  Repeat/PgDn |  Shift + Text |
|  Repeat/PgDn |  Shift + Ch - |
|  Subtitle/PgUp |  Subt |
|  Subtitle/PgUp |  Shift + Ch + |

| Original | Replacement |
|---|---|
|  <</Index |  << |
|  >>/Size |  >> |
|  I<</Reveal |  I<< |
|  >>I/Subpage |  >>I |
|  Red/Program |  Red |
|  Red/Program |  Shift + Sleep |
|  Green/Zoom |  Green |
|  Green/Zoom |  Shift + Eject |
|  Yellow/Slow |  Yellow |
|  Cyan/A-B |  Blue |

