






































































Original		Replacement		Original		Replacement	
	Power		Power		Down / PR-		Ch -
	Info		Info		Right / Vol+		Right
	Mute		Mute		Right / Vol+		Vol +
	Picture		Format		Left / Vol-		Left
	V.Size		3D		Left / Vol-		Vol -
	Source		AV		Menu		Menu
	Sound		Dual		Menu		Ok
	S.Mode	 + 	Shift + Dual		1		1
	Still		Pause		2		2
	Digest		Smart		3		3
	Pre.PR		Back		4		4
	Sleep		Sleep		5		5
	Text		Text		6		6
	Exit		Exit		7		7
	Up / PR+		Up		8		8
	Up / PR+		Ch +		9		9
	Down / PR-		Down		0		0



